

Digital **Wireless** Intercom



- Single Channel / 1 Button
- Digital Audio Communication
- Free from Interference
- Long Range
- Reliable & Simple
- Easy Installation
- Portable Handset
- Low Cost System
- Rainproof & UV resistant
- Gate Triggering



FEATURES

- Digital Radio Communication
- Hands-free Use for Visitor & PTT for Resident
- Gate Triggering (relay included)
- Gate powered from supply or gate motor 12v
- Gatestation battery Back-up with 3 AAA batteries (not included)
- Manual Programming (see manual for details)
- Mount Open on gooseneck or against wall
- Selectable audio, visual or vibration alert
- Outdoor temperature reading on handset
- Handset with rechargeable Li-ion battery
- Low risk of lightning damage
- Out-of-range and low battery level alert
- Multiple Handsets (ZA-651 optional extra handset)
- Additional Gatestations (ZA-652 optional extra gatestation)
- Intercom function between handsets
- 1 Year limited warranty
- Fully approved by ICASA

Range in a Built-up area



Further Range in Open Terrain



PACK OPTIONS:

ZA-650-A Kit:
Gatestation with Handset

ZA-650 Kit:
Gatestation (including Regulated Power Supply)
with Handset


ZA-651 Extra Handset

ZA-652 Extra Gatestation (Add / Back)
(including Regulated Power Supply)

Zartek
www.zartek.co.za




Basic Operation



VISITOR
PRESSES



HANDSET
RINGS &
ANSWERED



VISITOR
SPEAKS




RESIDENT
PRESSES
TO SPEAK




RESIDENT
OPENS
GATE

Controls Layout



Caller unit




Handset



Charging Stand

- | | |
|------------------------|-------------------------------------|
| 1. Call button | 12. Hang up and power ON/OFF button |
| 2. Microphone | 13. Door lock open button |
| 3. Speaker | 14. Press-to-talk (PTT) button |
| 4. Call indicator | 15. Microphone |
| 5. Light sensor | 16. Battery door lock button |
| 6. Temperature sensor | 17. Speaker |
| 7. Pairing button | 18. Li battery socket |
| 8. Terminal block | 19. Charging contacts |
| 9. Volume up button | 20. Charging indicator |
| 10. Volume down button | 21. DC jack |
| 11. Answer button | |

LCD



■ Flashing

■ Steady light up

A Frontgate doorbell ringing

B Backgate doorbell ringing

C Missed call
F (Frontgate)
B (Backgate)

D Reception mode

E Out of range alert
F (Frontgate)
B (Backgate)

F Door chime alert selected

G Flashing light alert selected

H Vibrating alert selected

I Door chime and flashing light alert selected

J Door chime and vibrating alert selected

K Flashing light and vibrating alert selected

L Door chime, flashing light and vibrating alert selected

M Door lock opened

N Caller unit battery low
F (Frontgate)
B (Backgate)

O Self battery low

P Battery level

Q Speaker volume

R Door lock de-activated