

FENCE TESTER - EASY



The Easy Fence Tester flashing rate changes with the change of voltage on the fence. The slower the rate the lower the voltage. The intensity of the light remains the same so it can be seen from far irrespective of the fence voltage. It is installed between the earth and live wire to indicate the status and condition of the fence for peace of mind.

Features:

- Includes clips to connect the wire or poly tape
- Indicates power on the fence for peace of mind
- Visible from up to 1km at night and 100m during the day
- No batteries required
- Uses minimal power from the fence
- The frequency of the flashing LEDs indicates the amount of energy on the fence. The longer the period between flashes, the lower the voltage on the fence
- Highly visible LEDs allow for a 160-degree viewing angle. This allows the light to shine into the secure area only
- Can operate from 0.9kV to 12kV
- Can be used with most electric fence energizers

Specifications:

Material	Plastic and water tight compound
Steel wire connectors	Black Fence Clips
Waterproof Housing	IP66
Flashing Rates	1. Flashing normally rate over ~7.5kV 2. Flashing at 25% slower than normal between 7.5kV~3kV 3. Flashing at 50% slower than normal between 3kV~2.5kV 4. Flashing at 75% slower than normal when less than ~2.5kV

Stock Code	Description
TL-EFT	Fence Tester - Easy