


Product Manual



Model: AERIS Gold Nebuliser

Power: 3W	Input Voltage: 5V=0.6A	N.W: 287g
Material: ABS+PP	Coverage: 15m²/45m³/1600ft³	Bottle: 10ml
Dimensions : Φ76*124mm	Li-battery: 2000mAh	


Product Description:



User Guide:



1. Take out the diffuser head




2. Turn the bottle counterclockwise



3. Press down the diffuser head



4. Long press to switch on the machine



5. Click to change the mode



6. Click to change the light colour

Function Description:

Charging mode

When charging, the indicator light is always red, and when fully charged, the green light is always on.
(Note: Refers to the charging indicator on the back)
Charge time: About 4h (When the battery is exhausted, it needs to be charged for at least 5 minutes before it can work again.
Battery duration: About 24h (working at M1)

Auto power off

The device will automatically power off after 3 hours of inactivity, provided no mode or colour changes are made during operation.

Ambient light

Total 9 light colors, they are red, orange, yellow, green, cyan, blue, purple, pink and white.

Diffuser head

Applied to 10ml bottles.


The Buttons

On/Off button: Long press to switch the machine, short press to change the mode.
Ambient light button: Press to change the light color or turn off the light.

Mode	Working time(s)	Stop time(s)
M3	10s	60s
M2	10s	120s
M1	5s	150s

Cautions:

- ⚠ 1. Please keep the machine vertical after installation.
Tilting or lying flatly may cause oil overflow. The machine efficiency may be affected if the circuit board is contaminated.
Note: The machine should be kept vertically to avoid leakage and damage when working.
- ⚠ 2. Should not modify, dismantle or repair the machine arbitrarily.
Any malfunction occurs, please contact HYSSES
- ⚠ 3. Do not put the machine in a hot or humid place to avoid damage to the machine.
- ⚠ Do NOT use quick charger for device.
- ⚠ Do NOT use or store the device above 60°C.



Cleaning & Maintenance:

- To ensure product is in good condition, please do a thorough cleaning and maintenance for the machine on twice a week basis using the following steps:
1. Remove the essential oil bottle after usage.
 2. Pour 10ml of HYSSES Cleaning Solution into the existing emptied and cleaned essential oil bottle. Alternatively, you may pour the cleaning solution into another empty essential oil bottle (10ml) and fit it back to the atomiser.
 3. Switch on the machine and let it run for 10 minutes.
 4. When everything is done, switch off the power.
 5. Pour away the excess HYSSES Cleaning Solution and add in your choice of essential oil.