


## IMPORTANT:

Before installing the smart lock, follow the below steps on this page to complete the installation of the lock cylinder.



Exterior Assembly

+



1

Lock Cylinder

+



2

Screw

## What You'll Need




Phillips-Head  
Screwdriver



## Lock Cylinder Installation Instructions

### Install the Lock Cylinder

- 1 Insert the lock cylinder into the cylinder hole of the exterior assembly.



- 2 Tighten the cylinder screw clockwise with a screwdriver.

