
INSTRUCTION



Tower Nebuliser Product instruction manual

Product Introduction

Micron Power. Amplified Aroma

A statement in scent technology. The HYSSES Tower Nebuliser combines sleek aesthetics with Micron Atomisation to deliver deep essential oil diffusion—customisable, cordless, remote-controlled and built to elevate large spaces.

Powered by advanced Micron Atomisation Technology, pure aromas flow effortlessly through your space—cleansing the air while awakening focus, calm, or energy on demand. Its bold design makes a confident statement, redefining any environment it enters. Built to impress, the sleek silhouette and long-lasting battery deliver smart, powerful scenting crafted for modern living.

Notice

Please read this instruction manual carefully before use.

- 1. For best performance, use only HYSSES Nebulising Oil with the Tower Nebuliser. Each blend is specially formulated to complement its pure Micron Atomisation system.
- 2. Do not use overloaded sockets, damaged power cables, or faulty adapters. Replace immediately if found defective to prevent fire hazards.
- 3. Do not attempt to modify, disassemble, or repair the equipment. If abnormalities occur, refer to this manual or contact Hysses at customer.care@hysses.com.
- 4. Do not invert or tilt the equipment while in operation. Before transporting, clean and maintain the device (see Maintenance) to prevent oil leakage and internal damage.
- 5. Regular cleaning and maintenance are essential to ensure optimal performance—ideally once a week or whenever switching to a new Hysses Nebulising Oil. This prevents scent mixing, blockage, and helps the device function at its best.
- 6. Use only with the provided adapter and power cord. Using other adapters may cause malfunction or damage to the device and will void the warranty.

Instructions for refilling oil

- Switch off the device and let it rest for 2 minutes before refilling. This allows the HYSSES Nebulising Oil to flow back into the bottle.
- Do not fill beyond 100ml. For best results, refill only the amount required to prevent oxidation and deterioration of the oil.

Product parameters

		Fog outlet	_
Dimension	Ф92*303.5(mm)	Yog outlet	Atomizing body
Capacity	100ml	<u> </u>	← Aluminum bottle
N.W	0.82KG		Dottle
Coverage	1,000 – 3,000 sq ft	1	
Voltage	Type-C 5V-2A		
Power	8W		
Charging Time	6-7 hours (for a full charge with the provided adapter and power cord)		
Packaging size	W113*D117*H395(mm)		
Battery Capacity	5000mAh	key	Power interface
Smart Safety	Dumping Sensor: Tilts >45° → buzzer sounds 3 times, unit stops working	positive	back

What's Included

- Tower Nebuliser Unit
- Atomiser Cord
- Power Cord (Type-C)
- 3 Pin Adapter
- Remote Control
- Aluminium Bottle (100ml)
- Flat Washer
- Connector Tube
- Warranty Card

Precautions for use













Remote version control introduction

1.Remote Face Panel

- Switch: Power on/off the device.
- 2) Misting for 30 seconds with a 5-minute pause (1 hr cycle)
- (3) Misting for 1 minute with a 1-minute pause (1 hr cycle)
- Misting for 5 minutes with a 1-minute pause (1 hr cycle)
- (5) 1 hr: Runs for 1 hour
- 6 4 hrs: Runs for 4 hours
- 7) 12 hrs: Runs for 12 hours

The device is designed with a safety feature that automatically powers off once the selected timer mode ends.






2.Operating

- Power On: Press the remote switch. The buzzer will beep once, and the device will start in 1st gear mode (indicator shows a steady blue light).
- Adjusting Gear/Time: Use the remote to change settings. A single beep will confirm each adjustment.
- Low Power: The red light will appear. Charging: The blue light will flash.
- Fully Charged: The blue light will remain steady.
- Tilt Safety: If the device tilts more than 45°, the buzzer will beep 3 times and the nebuliser will automatically stop misting.

Installation guide



- 1. Rotate the atomiser counterclockwise ① and lift it out with the aluminium bottle ②.
- 2. Hold the aluminium bottle and turn it counterclockwise to detach from the atomiser ③.
- 3. Fill the bottle with Hysses Nebulising Oil (up to 100ml maximum).
- 4. Reattach the bottle to the atomiser clockwise until tight (4).
- 5. Place the atomiser and bottle back into the unit and secure clockwise (5).
- 6. Press the remote control to start operation (6).

Equipment maintenance

To maintain optimal performance, regular cleaning and upkeep are essential—ideally once a week or each time you switch to a new Hysses Nebulising Oil. This prevents scent mixing, avoids blockages, and ensures your device operates optimally.

- 1. Unscrew and remove the used Hysses Nebulising Oil aluminium bottle.
- 2. Pour an appropriate amount of HYSSES Cleaning Solution into an empty aluminium bottle and rinse.
- 3. After rinsing, add a small amount of cleaning solution, attach the bottle back, and run the unit for 10 to 15 minutes.
- 4. Power off the device after cleaning.

Warranty card

A separate Warranty Card is included in the packaging. Please refer to the card for warranty terms, conditions, and claim procedures.