

Thank you for purchasing a Wham Bam **ULTIM8 FUN**.

The ULTIM8 FUN is the most amazing funnel you will ever have for resin transfer, filtering, cleaning, and so much more.

Made specifically for resin printing and clean up!

### To Use:

To use while pouring and filtering resin from the resin vat back to the bottle simply place the ULTIM8 FUN into the bottle, add a paper conical filter. If the filter has top tabs, you can lock these onto the top hooks.

Pour your resin through the filter and into the bottle.

When done, throw away the filter cone, and wipe down with IPA. It can be compressed to fit into your wash station.

To use while pouring and filtering IPA, first effectuate a rough pour through paper conical filters as described above, then use our 3D printable shelf, link can be found on our support page, or [here](#). Position this on the inner ledge of the ULTIM8 FUN and place a round Ø110 disc of fine filter paper to do a fine particulate filter of your IPA to clean it as much as possible. Repeat as many times as needed.

For better IPA cleaning results first pour your IPA into a glass jar, trying not to get any of the the bottom sludge into the jar. Then expose this to sunlight for a few days and leave to sit to help to drop hardened particulates to the bottom, then carefully pour the top clearer portion through the ULTIM8 FUN with paper disk.

The ULTIM8 FUN's high-grade silicone will not be harmed by IPA nor chemicals in resins.

### Unique Features:

- 100% first grade silicone for easy cleaning and superior resistance to IPA, Resins, or most other corrosive chemicals.
- External fluted design allows air to escape from the bottle for smooth and fast transfers.
- Fluted interior to allow for resin passage when using conic paper filters.
- 2 filter hooks to secure the paper filters with top tabs.
- 2 handles for lifting and transfer.
- Inner ledge to accommodate a printable filter shelf that allows use of Ø110 fine filter disc papers.
- Folds Flat if needed to store in tight spaces.
- Wipes clean easily!

### First Use:

After receiving the ULTIM8 FUN or after long periods stored flat you can easily massage it back into shape.

*Attention: when working with resin always use the appropriate eye protection and gloves to avoid contact with the resin\**

### Resources, Help, and Support:

Should you have any issues please refer to our installation guide, FAQ's, and to find the most up to date instructions please go to our page: <http://bit.ly/FDMsupport>

For any other support and resources, and feel free to write us with any questions.

ordering / shipping: [info@whambamsystems.com](mailto:info@whambamsystems.com)

technical support: [technical@whambamsystems.com](mailto:technical@whambamsystems.com)

**Wham Bam thanks you for your support and welcomes any and all feedback!**

