

Zeno Series



PGK728WRHK

Start Second

Lockly Visage

Setup and Use

LOCKLY
Enjoy the freedom™



We're Here to Help

Your Lockly smart lock comes with lifetime technical support. Feel free to contact us with any questions or comments.



(669) 500-8835



help@Lockly.com



support.Lockly.com

Setup

App Download	04
Charge/Install Battery	05/6
Lock Overview	07/8
Facial Recognition	09
Apple Home	10
Fingerprint Access	11
Adding a Fingerprint	12

Download the Lockly Home App

Scan or visit [Lockly.com/app](https://lockly.com/app)




The Lockly Home App will guide you through final installation, setup, and creating your user profile for a more tailored and optimized experience.

Charge the Battery

Ensure battery has been fully charged.

Charge the battery with the included USB-C cable and a common mobile device charger (not included) rated 5V/2A or higher. A full charge can take up to 12 hours.




Install Battery and Start Self-Check

Ensure battery has been fully charged.

Install battery as shown.

Perform Self-Check (skip if done)
Immediately hold the red program button for 4 seconds. The lock will perform a self-diagnostic by extending and retracting the deadbolt multiple times.


Open the Lockly Home App and tap (+) to add a new device. Locate your Lockly model and follow in-app instructions to continue setup.




Bluetooth pairing stops after 10 minutes of powering on and cannot be paired with the Lockly Home App. To re-enter pairing mode, reinstall the battery or press the Program button and click "BL" in the circle on the keypad to re-enable Bluetooth pairing.

Getting to Know Your Lockly Visage

Exterior




Interior



Set up Facial Recognition

Ensure battery has been fully charged.



Environment

For optimum performance, ensure the area is well-lit but not too bright.

Facial Recognition Positioning

For optimal recognition stand between 1 to 3 feet directly in front of the lock.

Register a Face


Choose your lock in the Lockly Home App and select **access**, then **user**, **facial recognition**, and follow the in-app instructions.



If you have a twin, a look-alike sibling, or a child under 13, we recommend using a PIN code, fingerprint, or mobile app for authentication.

Set up Apple Home

Unlock your door with your iPhone or Apple Watch and monitor its status through the Home app.



Open Apple's **Home app** and select **(+)**, **Add Accessory**.

Locate the Apple HomeKit code under the battery cover or on the activation card. Scan code when prompted.

Follow the in-app instructions to add your Home Key to your Wallet app.



To share access and control remotely through Apple Home, you will need one of the following as a home hub:

- Apple TV® (4th gen, tvOS 12.0 or higher)
- iPad® (iOS 12.0 or higher)
- HomePod® or HomePod mini®

Set up Fingerprint Access

Fingerprint Scanning


For fast and reliable fingerprint recognition, it's important to follow correct finger positioning when registering your fingerprints.



Alignment

Avoid positioning finger too high or low on the sensor.

Avoid positioning finger too much off-center left or right.




Angle

Keep finger straight and somewhat flat; avoid holding at an angle.

Adding a Fingerprint


In the Lockly Home App, choose your lock then select "Access" and follow on-screen instructions.



Scanning Process

Your finger will be scanned six times for optimal accuracy. The countdown shows in the lower-left circle of the digital screen, starting from six.

Place your finger on the sensor and hold still until you hear a beep. Slightly adjust your finger position and hold for each remaining scan until you hear a longer beep with the word "pass" indicating a successful scan.



If fingerprint registration fails, repeat process.


Use

PIN Genie Keypad	14
Unlock with Keypad	15
Adding a PIN Code	16
Auto and Manual Lock	17
Facial Recognition	18
Fingerprint Access	19
Apple Home Keys	20
Unlock with App	21
More Ways to Access	22/23
Alert and Sounds	24
Troubleshooting/FAQs	25/26

PIN Genie™ Keypad

Dynamic Shuffling Technology

Exclusive hack-proof PIN Genie digital keypad shuffles PIN (personal identification number) between each use.



The same PIN shuffles location between each use.

Using

PIN codes are made up of six digits, for example **3 5 1 2 9 0**. Each number can show up anywhere in one of three positions inside for circles.

Simply press anywhere on a circle containing the corresponding number to enter your six digit PIN code.

Unlocking


After all six numbers are entered press the enter button  to unlock.

Note: the default PIN code is 1 2 3 4 5 6




You can toggle between dynamic shuffling and always fixed number location by pressing the enter button for 3 seconds.

Unlock with Digital Keypad



Unlock

Swipe your hand across the screen to activate the keypad.



Enter your PIN code by pressing anywhere in the circles that contain the corresponding numbers; you do not need to press the exact number.

Press the **enter** button after the last digit of your PIN code has been entered.

Lock

To lock, press the enter button while the screen is active, or swipe your hand across the screen while the screen is off.



Temporarily boost screen brightness by pressing and holding any of the 4 circular number buttons for 3 seconds.

Adding Additional Access Codes

Access Code Types

Set permanent, recurring, time-based, or one-time use access codes.




Default PIN Code


The default PIN code is 1 2 3 4 5 6. During setup, you will be prompted to set a new code to replace it.


Adding a Code

Select your lock from the Lockly Home App, then select **Access** then **user**, **Access Code** and follow the on-screen instructions to setup the various types of codes.



Auto and Manual Locking

When unlocked the  icon will appear on screen.



Auto-Locking

In the Lockly Home App, set your desired time (example 5-min) under **settings** of your lock, **auto-lock timer**.

Lock Using Digital Screen

Swipe top to bottom with two fingers when screen is off or press the enter button when screen is on.



Interior Locking

Rotate the thumbturn on the interior assembly.

Lock with Key

Insert physical key and rotate.




Unlock with Facial Recognition



Recognition

Stand 1 – 3 feet (0.4m - 1m) directly in front of the lock.

The LED ring light around the fingerprint sensor indicates the following for facial recognition:

-  **Blue Light:** face detected; scan started
-  **Green Light:** door is unlocked
-  **Red Light:** adjust your distance and ensure nothing is obstructing your face*

For security reasons, facial recognition will be temporarily disabled after eight failed attempts within two minutes.


*See troubleshooting to learn more.



To conserve battery, facial recognition is automatically disabled when the battery power drops below 20%. To reactivate it, install a fresh battery.

Unlock with Your Finger

Featuring advanced AI learning technology.



Place a registered finger flat and centered on the sensor.

Green Circular LED: with a beep; door is unlocked.

Red Circular LED: with two beeps; finger not recognized. Try again or try another registered finger.



Our advanced biometric sensor with AI learning technology recognizes your fingerprint in 0.2 seconds and improves in speed and accuracy with use.

Unlock with Apple Home Keys


Open your door with your iPhone and Apple Watch.


Unlock your door with home key in Apple Wallet (on your compatible iPhone and Apple Watch).

Set up a Home Key

Add your Lockly lock to the Home app. Choose the "Express Mode" unlocking option.

Unlock Your Door with a Home Key

On your iPhone or Apple Watch and with Express Mode turned on, place your device near the  icon to unlock.



Learn more about home key in Apple Wallet on the iPhone User Guide online at: support.apple.com

Unlock with Lockly Home App

Lock, unlock, and check status.

Unlock or Lock

Choose your lock in the Lockly Home App, tap unlock or lock.

Remote App Control

Unlock, lock, check status, and get notifications from anywhere on your smartphone.

History and Status Monitoring

Check real-time status and history on your smartphone.



More Ways to Access and Control

Secure access, control, and monitoring options.



eKeys and eBadges

Share one-time, permanent, recurring, or revocable access with people you trust.



Voice Control

Unlock, lock, or check door status through Amazon Alexa, Apple Siri, and Google Assistant.



Offline Access Codes™

Grant one-time access through the Lockly Home App without needing an internet connection.



Welcome Mode

Temporarily keep your lock from auto-locking for more convenient trusted user access.



We introduce new features every year. Subscribe to our newsletter at lockly.com for product updates, tips, and the latest innovations.



History and Status Monitoring

Check real-time status and history on your smartphone.



Air Transfer™

Easily transfer user profiles between Lockly device for seamless setup and access management.



Set up User Privileges

Grant sub-admin privileges to allow others to manage your property.



Manage Multiple Properties

Manage access control and reporting with LocklyOS, the cloud platform for property access management.

For more information, refer to the Lockly Home App or visit support.Lockly.com.

Alerts and Sounds

Exterior Assembly Alerts

Facial Recognition

Exterior LED indicator flashes blue	Approach detected; Facial recognition started
Exterior LED indicator flashes green	Door unlocked
Exterior LED indicator flashes red	Facial recognition failed

Fingerptint

Exterior LED indicator flashes green with a 'beep' sound	Door unlocked
Exterior LED indicator flashes red with two 'beep' sounds	Fingerprint recognition failed

Access Code

Exterior LED indicator flashes green	Door unlocked
Exterior LED indicator flashes red	Incorrect access code entered

Apple Home Key / Voice Control

Exterior LED indicator flashes green	Door unlocked
--------------------------------------	---------------


Interior Assembly Alerts

Battery

Interior LED indicator flashes red with a beep sound (x3)	Battery level is less than 20%
Interior LED indicator flashes red with a beep sound (x5)	Battery level is critically low (3 unlocks remaining). Charge battery immediately.

Troubleshooting/FAQs

Why Is My Keypad Not Responding?

- Swipe your hand across the screen to activate the keypad.
- If  is flashing, your smart lock is in **Safe Mode**. Unlock with other access credentials (fingerprint, mobile app, home key or physical key) to exit.
- If water is detected, Rain Mode may be activated. Unlock your door with other authentication methods (Apple Home Keys, facial recognition, Lockly Home App).
- Check if battery is installed correctly.
- Refer to [support.Lockly.com](https://support.lockly.com) for more information about **Safe Mode** and **Rain Mode**.

Why Is My Keypad On Full Blackout?

- Battery may have been completely depleted. Use the physical key or a Type-C cable to connect your Lockly to a mobile power source to temporarily activate the lock. Charge the battery immediately after unlock.

Why Is My Facial Recognition Sensor Not Responding?

- Check the battery level. To extend battery life, facial recognition will be disabled when battery level is dropped below 20%. Charge the battery to reactivate the sensor.
- Facial recognition sensor will be temporarily disabled after consecutive incorrect attempts. Try again after 30 minutes or unlock with other authentication methods (fingerprint, access code, Lockly Home App) to re-activate.

Why Is My Fingerprint Not Recognized?

- Check that you are using a registered finger.
- Make sure your finger is clean and dry.
- Position your finger at the center of the sensor.

Troubleshooting/FAQs

Why Is My Lockly Not Locked Automatically?

- Check if auto lock is disabled in the Lockly Home App.
- **Welcome mode** is currently active. Disable or change setting in Lockly Home App.

Why Is the Battery of My Lockly Visage Depleting Quickly?

- Refer to support.Lockly.com for more tips to improve battery life.

How to Pair My Smart Lock with a New Phone?

- Download the Lockly Home App on your new device and log in using the same account credentials, follow in-app instructions.

How to Pair My Smart Lock with a New Lockly Account?

- You will need to perform a factory reset with the following steps.
 1. On the old Lockly Home App account, go to Settings > Reset and Pairing > Perform Factory Reset
 2. Download, register and log in to the new Lockly Home App account. You will need your activation card to set up the device.
- You can perform factory reset on the lock. Refer to Lockly Home App or support.Lockly.com for more details.

Lockly Technical Support

(669) 500-8835

help@Lockly.com

support.Lockly.com

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. It should be installed and operated with a minimum distance of 20cm between the radiator & your body.

IC WARNING

This device contains license-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC Radiation Exposure Statement

This equipment meets the exemption from the routine evaluation limits in section 2.5 of RSS-102. It should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Cet équipement est conforme à l'exemption des limites d'évaluation habituelle de la section 2.5 de la norme RSS-102. Il doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et toute partie de votre corps.



WARNING: Cancer risk from exposure to Lead. See www.P65Warnings.ca.gov.

Let's co-create together!

Have an innovative idea?
Need a new solution for a situation?

Let us know. We are always innovating based
on customer input and feedback.
(669) 500-8835 or hello@Lockly.com

Own a business?

Learn about how LocklyPRO and LocklyOS
can help you in your business.

(510) 288-9928 or prosales@Lockly.com



© Copyright 2025 Lockly All Rights Reserved

Patent No. US 9,881,146 B2 | US 9,853,815 B2 | US 9,665,706 B2 | More patents refer to <https://lockly.com/pages/our-patents>

Use of the Works with Apple badge means that an accessory has been designed to work specifically with the technology identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc., and any use of such marks by Lockly is under license. Other trademarks and trade names are those of their respective owners. Google, Android, Google Play and Google Home are trademarks of Google LLC., Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc., or its affiliates. Apple, Apple Home, Apple Watch, HomeKit, HomePod, HomePod mini, iPad, iPad Air, iPhone, and tvOS are trademarks of Apple Inc., registered in the U.S. and other countries and regions.

© Copyright 2025 Lockly All rights reserved.

(See details on the inside back cover).