



Technical Sheet - code GS001 FFP2 NR

FILTERING FACE MASK FFP2

DESCRIPTION

- Rexpiria® GS001 FFP2 NR Filtering Facial Mask offers effective protection of the respiratory tract from solid and / or non-volatile liquid particles (dust, fumes, mists).
- Folding filter body.
- Nose underwire able to ensure excellent adaptability to any type of face.
- Comfortable elastic bands.
- NR marking: indicates that the filtering face mask is disposable and not reusable for more than one use activity.
- Product tested and CE certified according to EN149: 2001 + A1: 2009 standard.
- Individually wrapped product to ensure hygiene and perfect conservation and avoid any contamination.

PACKAGING

- Envelope containing 5 pieces
- Box containing 10 pieces

MATERIALS

- Filter body composed of four layers of non-woven polypropylene fabric.
- Spandex elastics
- Weight: 4 grams

STORAGE AND TRANSPORTATION

Rexpiria ® GS001 FFP2 NR Filtering Facial Mask has a lifespan of 3 years. The expiry date is indicated on each pack. The product must be stored in a clean and dry environment, in a temperature range between + 5 ° C and + 40 ° C and with a relative humidity lower than 80%. For storage and / or transport, use the original packaging.

CERTIFICATIONS

Rexpiria® GS001 FFP2 NR Filtering Facial Mask meets European Directive 89/686 / EEC (Personal Protective Equipment) requirements and is CE certified as Category III PPE, in accordance with the technical standard EN 149: 2001 + A1: 2009. CE certification and control are carried out by Universal Certification (Notified Body number 2163).

The products are made in an ISO9001 certified factory.

Certification tests performed:

- Filtering material efficiency
- Total filtering efficiency
- Flammability
- Carbon dioxide content of the inspired air
- Respiratory resistance

WARNINGS

- User must be trained in the correct use of the product before its use.
- Please read carefully instructions contained in the multilingual instruction manual.
- The filtering face mask does not protect against gases and vapors for which the use of suitable devices is necessary (half-masks and full masks with gas filters).
- Do not use in an environment with insufficient oxygen content (<17%).
- Do not use when the concentrations of the contaminant are immediately dangerous to health.
- Immediately leave the work area if breathing becomes difficult or if you feel discomfort, nausea and / or dizziness.
- Do not modify or alter the product in any way.
- The filtering face mask is disposable and cannot be reused for more than single use activity.
- Use is not recommended in the presence of physical conditions (beard or long sideburns) that do not allow direct contact between the face and the sealing edges of the filtering mask.



GOLDEN SEASON SRL

P. IVA / VAT 03233670987 - REA BS-516795 | Legal: via Corfù 66, 25124 Brescia - IT

HQ: via dell'Industria 61, 25030 Erbusco (BS) - IT - Tel +39 030 72 37 77 - Fax +39 030 77 06 867

Logistics: via Verona 37, 37017 Lazise (VR) - IT