


STRATFORD PARCEL MAILBOX INSTALLATION


TOOLS & SUPPLIES



Wrench



Measuring tape




Level

Concrete Anchors








Concrete Bit



Hammer Drill

INSTRUCTIONS

1. Build concrete slab for mailbox mounting base. Front of the mailbox must be 6"-8" from the back of the curb. Concrete slab must be at minimum 10" deep if freestanding or 4" deep if connected to existing sidewalk or driveway.
2. Open the back parcel door and remove bottom pan.
3. Mark hole location of existing laser cut holes in the bottom of the mailbox. Make sure the front of the mailbox is 6"-8" from the back of the curb.
4. Move mailbox out of the way and drill the holes for the anchors.
5. Place mailbox back over hole locations. Check plumb with level. Shim if necessary. Insert anchors and bolt down mailbox.
6. Insert bottom pan over bolts to keep your packages out of the elements.



Per U.S. Postal Service Standard – Mailboxes, Curbside, paragraph 3.12.1

Assembly and Installation: A complete set of instructions for assembling and mounting the mailbox shall be furnished with each unit. The instructions must include the following conspicuous message:

PURCHASER IS REQUIRED TO CONTACT THE LOCAL POST OFFICE BEFORE INSTALLING THE MAILBOX TO ENSURE ITS CORRECT PLACEMENT AND HEIGHT AT THE STREET. GENERALLY, MAILBOXES ARE INSTALLED AT A HEIGHT OF 41 - 45 in. FROM THE ROAD SURFACE TO INSIDE FLOOR OF THE MAILBOX OR POINT OF MAIL ENTRY (LOCKED DESIGNS) AND ARE SET BACK 6 - 8 in. FROM FRONT FACE OF CURB OR ROAD EDGE TO THE MAILBOX DOOR.

Have questions? Please contact us at sales@boldmfg.com