


# HOW TO INFLATE YOUR TIRES IN 6 QUICK STEPS


1

Get a tire pressure gauge: digital or pencil style are available online for a reasonable price.



2

Ensure your tires are cold. Do this operation first thing in the morning or in between drives.



3

Identify the recommended pressure: check psi value on tires, driver's manual, doors or even gas tank cap.



4

Remove the valve stems cap and fill up each tire, using the air dispenser, to its recommended amount.



5

Make sure not to overfill. A tire below or above its recommended pressure is a serious hazard.



6

Replace the caps, check that the correct pressure has been reached for each tire. You are good to go!

