


The Lockly Wireless Door Sensor is compatible with PGH260, PGH230, and PGH222 Wi-Fi Hubs for full functionality. It utilizes bidirectional RF433.92MHz and Lockly 2.0 proprietary encryption for stable, secure communication. You can install it easily anywhere, and it runs on one AAA battery for a long time. It checks if the door is fully closed to prevent any risks. Additionally, it sends instant push notifications to your phone when the door is locked or unlocked, keeping you informed about your security status.

The Door Sensor comes in two parts. Depending on your door orientation, the door sensor will be mounted in different ways.

Part 1 - Door  
Frame Sensor

Part 2 - Door  
Sensor Magnet




### Preparation

Before installation, ensure the indoor surface where you plan to place the Door Sensor is clean and dry. Wipe the surfaces of the door and door frame gently, and confirm they are dry. Do not install the sensor immediately.


Keep the Door Sensor away from direct sunlight, high temperature areas, and large metal objects, as these may disrupt wireless signals. For the best performance and safety, install the sensor at the upper corners of the door, out of reach of children and pets.

When you are installing the Door Sensor, make sure the arrows on the Door Sensor Magnet is placed next to the arrow from the Door Frame Sensor.


WHEN FACING YOUR DOOR FROM THE INSIDE, DOOR HINGES ARE ON THE RIGHT SIDE



WHEN FACING YOUR DOOR FROM THE INSIDE, DOOR HINGES ARE ON THE LEFT SIDE




When installed on your door, the distance between the Door Sensor and the Door Frame Sensor must be less than  $3/4$ " in order for the sensor to work.



## Install the battery

Open the door sensor as shown, put in 1 AAA battery, please pay attention to the positive and negative poles of the battery.



Slide and Lift to remove cover to replace the AAA/LR03 battery.

## Pair the Door Sensor

1. Open the Lockly Home app and navigate to: Settings > Wi-Fi Settings > Add New Sensor > Wireless Door Sensor.


Note: Please follow the app's menu layout for all operations.

2. Install the battery. The blue indicator light will flash for 3 minutes. Tap Continue in the app to proceed.

3. Press the setup button 3 times within 2 seconds to start pairing.

4. Success: The blue light will stay ON for 2 seconds before going off.  
Failure: The blue light will continue flashing.

Retry: Press the setup button 3 times again immediately to re-pair  
5. If no action is taken within 3 minutes, pairing mode will exit automatically. Please return to the previous app step. Remove and reinstall the battery, then repeat the pairing process from Step 2.



If the pairing is unsuccessful, reinstall the battery and re-enter the pairing mode as described above. Mount the Door Sensor and Sensor Magnet once pairing is successful.

Note: After pairing the wireless door sensor with the lock, you must remove it in the app under Lock Settings before pairing it again with another lock.

#### IMPORTANT

- Do not allow the battery to corrode or leak as this may cause permanent damage to the product.
- Make sure to insert battery on correct polarity as shown inside the battery compartments.
- Do not use rechargeable batteries.
- When battery is drained, do not dispose with normal household waste. Dispose via suitable recycling center. DO NOT BURN.

### **FCC Warning :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE 1:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**NOTE 2:** Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **FCC Radiation Exposure Statement**

Lockly Wireless Door Sensor complies with FCC radiation exposure limits set forth for an uncontrolled environment. It should be installed and operated with minimum distance 20cm between the radiator & your body.

## IC WARNING

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device. L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### IC Radiation Exposure Statement

This equipment meets the exemption from the routine evaluation limits in section 2.5 of RSS-102. It should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Cet équipement est conforme à l'exemption des limites d'évaluation habituelle de la section 2.5 de la norme RSS-102. Il doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et toute partie de votre corps.



**WARNING:** Cancer risk from exposure to Lead. See [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).